



WATERSHED™

BATH PRODUCTS

## Multi-Piece Bathtub/Shower w/Surround Installation

## ALCOVE PREP

Ensure the alcove is the proper size, square, plumb and clean of dirt/debris.



# STEP 1

Install drain of choice according to manufacturer instructions.



## STEP 2



Apply a 1/4" bead of silicone caulk around the top of flange.



## STEP 3



Set one side panel in place.

Apply a ¼" bead of silicone caulk along the vertical flange/panel seam.

## STEP 4



Set second panel in place.



## STEP 5



Pre-drill holes on the back panel vertical flange, 12" apart.

Install recommended hardware.

*1" x 1/4" bolt w/nut and 2 washers recommended (not included)*



## STEP 6



Pre-drill screw holes on the back horizontal flange and install hardware.

Start in front on both sides to hold in place.

Work around toward the center seam.



## STEP 7



Mark holes needed for plumbing fixtures on back of unit.

Measure carefully.

## STEP 8



Drill pilot  
hole(s) from  
back.



Cut hole(s) from front  
using correct size hole saw.





## STEP 9



Position assembled unit into alcove.

Align drain with waste pipe.

Check for level.  
Adjust/Shim as needed.



## STEP 10

Locate studs and mark.

Pre-drill screw holes through flange at the stud markings.



Side/vertical flange holes should be about 12" apart.

## STEP 11

Install screws,  
beginning with  
all points where  
panels meet...



*No.8 screws recommended  
(not included)*

## STEP 12



...then working from the center of the back panel around to the front and down.



# FINISHING TOUCHES

- Install plumbing fixtures
- Complete walls and edging according to homeowner preferences (trim, moulding, tile, wall panels, shower doors, etc.)
- Clean with mild detergent and warm water (no abrasive chemicals or materials)





WATERSHED™  
BATH PRODUCTS

ENJOY!

Visit  
[stylecrestinc.com/watershed](https://stylecrestinc.com/watershed)  
for more information